


Removing

1. If you can fold the trolley up and take the screws out in the back of the handle

(there are 6 along the back and 2 down the way).



2. Once you take the back of the handle away you will find the switch connector plug.
3. Unscrew the large screw on the outside of the handle holding the knob in place



*switch
connector*

*nut holding the switch
knob in place*